

SPEC SHEET + MEASUREMENTS



Bulwark® EXCEL FR® ComforTouch® Dress Uniform Shirt. SLU2

Product photo



Arc Rating ATPV 8.6 calories/cm²

FABRIC Flame-resistant EXCEL FR® ComforTouch® 7-ounce, 88/12 cotton/nylon

FEATURES Industrial laundry friendly. Banded, topstitched, button-down collar. Placket front with button closure. Tailored sleeve plackets. Topstitched cuffs with button closures.

STANDARDS This flame-resistant garment meets the requirements of NFPA 2112, Standard on Flame-Resistant Garments for Protection of Industrial Personnel Against Flash Fire 2018 Edition; EN ISO 11612:2008, Protective Clothing Against Heat and Flame; EN 340:2003, Protective Clothing--General Requirements; and IEC 61482-2:2009, Live Working--Protective Clothing Against the Thermal Hazards of an Electric Arc.

CARE INSTRUCTIONS

Machine wash inside out with like colors. No bleach. No starch or fabric softeners. No products containing hydrogen peroxide. Tumble dry. Failure to launder properly could affect the flame resistance.

Sketches



front



back

SPEC SHEET + MEASUREMENTS



Bulwark® EXCEL FR® ComforTouch® Dress Uniform Shirt. SLU2

PRODUCT MEASUREMENTS

| | S | M | L | XL | 2XL | 3XL | 4XL |
|--------------------------------|--------|--------|--------|--------|--------|--------|--------|
| Chest | 47 3/8 | 51 3/8 | 55 3/8 | 59 3/8 | 63 3/8 | 67 3/8 | 71 3/8 |
| Body Length at Back | 33 1/4 | 33 5/8 | 34 | 34 3/8 | 34 3/4 | 35 1/8 | 35 1/2 |
| Sleeve Length from Center Back | 34 1/8 | 34 5/8 | 35 1/8 | 35 5/8 | 36 1/8 | 36 1/8 | 36 1/8 |

Chest: Measured across the chest one inch below armhole when laid flat.

Body Length at Back: Measured from high point shoulder to finished hem at back.

Sleeve Length from Center Back: Measure from Center Back neck to shoulder point to sleeve hem.

SIZE CHARTS


| | S | M | L | XL | 2XL | 3XL |
|-------|---------------|---------------|---------------|---------------|---------------|---------------|
| Neck | 13 5/8-14 1/2 | 14 5/8-15 1/2 | 15 5/8-16 1/2 | 16 5/8-17 1/2 | 17 5/8-18 1/2 | 18 5/8-19 1/2 |
| Chest | 32 1/2-36 | 36 1/2-40 | 40 1/2-44 | 44 1/2-48 | 48 1/2-52 | 52 1/2-56 |
| Arm | 33 | 33 1/2 | 34 | 34 1/2 | 35 | 35 |

SPEC SHEET + MEASUREMENTS



Bulwark® EXCEL FR® ComforTouch® Dress Uniform
Shirt. SLU2

HOW TO MEASURE



Neck Measure around the fullest part of the neck at the base.
Chest Width Measure under the arm and around the fullest part of the chest with arms down, keeping tape horizontal. **Arm** Place hand on hip. Start at the center of the back of the neck and measure across the shoulder, to the elbow, and then down to the wrist.

COLORS

Please note: PMS code information is shown only when an exact match is available.



Khaki
PMS 7503C



Light Blue
PMS 346C



Navy
PMS 433C



Silver Grey